

SeaLand® J-series Vacuum Generator Duckbill Valve Installation Instructions

INLET DUCKBILL VALVE REPLACEMENT:

1. If possible, flush plenty of fresh water through vacuum generator.
2. Disconnect power to vacuum generator by unplugging wires between vacuum switch and pump motor.
3. Remove four 1/4-20x1 inch long hex head screws that secure the pump to tank.
4. Lift pump body away from tank to expose two inlet duckbill valves.
5. Remove the upper duckbill valve from the bottom of the pump body.
6. Remove the collar and lower duckbill from the vacuum tank.
7. Place new duckbill valve in collar and place assembly into center of vacuum tank with duckbill pointing up (as shown). The collar/duckbill valve assembly must be in center of hole.
8. Place new duckbill valve on top of collar in tank opening.
9. Making sure sealing ring is positioned properly in top groove of tank, carefully replace the pump assembly into the top of the tank, and secure with the four hex head screws.


OUTLET DUCKBILL VALVE REPLACEMENT:

1. Disconnect power to vacuum generator by unplugging wires between switch and pump motor.
2. Unscrew swivel nut where hose is attached to pump outlet. Remove swivel nut/hose from transition adapter.
3. Unscrew transition adapter and valve adapter to expose two duckbill valves.
4. Replace both duckbill valves.
5. Reassemble pump outlet components, making sure all connections are tight.
6. Reconnect power to vacuum generator. Test system for vacuum leaks before using.



Caution

Pump starts automatically. Turn off power to pump before servicing.



J SERIES VACUUM GENERATOR

SeaLand®
by Dometic GROUP

Dometic Corporation
13128 State Rt 226
PO Box 38
Big Prairie, OH 44611
1-800-321-9886